
Avr-Microcontrollers-in-Linux-Howto

	Revision History	
Revision 44	2009-04-20 17:13:07	jdd
	obfuscate e-mail at the author demand	
Revision 43	2009-03-29 20:49:12	ranjeeth
Revision 42	2009-03-29 20:45:09	jdd
	reverting after publication	
Revision 41	2009-03-29 20:41:59	jdd
	edit to export docbook	
Revision 40	2009-03-28 21:07:57	RickMoen
	Adjust style of mailto link to author's original preference.	
Revision 39	2009-03-28 21:05:45	RickMoen
	Revert e-mail obfuscation, supply some missing punctuation, [re-]fix capitalisation, fix and clarify new run-on sentence.	
Revision 38	2009-03-23 18:21:24	ranjeeth
Revision 37	2009-03-23 18:19:51	ranjeeth
Revision 36	2009-03-23 17:20:32	ranjeeth
Revision 35	2009-03-23 17:19:47	ranjeeth
Revision 34	2009-03-23 10:26:00	jdd
	publishing tests	
Revision 33	2009-03-23 10:25:06	jdd
Revision 32	2009-03-23 10:24:24	jdd
	use of macro to obfuscate e-mail	
Revision 31	2009-03-23 10:11:47	jdd
	change was only to export docbook without admonitions	
Revision 30	2009-03-23 10:09:15	jdd
Revision 29	2009-03-23 10:05:07	jdd
Revision 28	2009-03-23 09:58:40	jdd
	adding the wiki as link	
Revision 27	2009-03-23 09:53:28	RickMoen
	Insert needed space characters into "pin9", "pin10", "pin25" constructs	
Revision 26	2009-03-23 09:49:05	RickMoen
	Make markup of all the software items mentioned be consistent	
Revision 25	2009-03-23 09:43:40	RickMoen
	Remove a couple of stray commas.	
Revision 24	2009-03-23 09:41:30	RickMoen
	Polishing up a few last bits of punctuation	
Revision 23	2009-03-23 04:11:31	ranjeeth
Revision 22	2009-03-23 04:10:34	ranjeeth
Revision 21	2009-03-23 04:09:07	ranjeeth
Revision 20	2009-03-17 16:20:27	ranjeeth
Revision 19	2009-03-17 16:18:33	ranjeeth
Revision 18	2009-03-16 19:10:30	RickMoen
	Fix hyperlink, fix English diction of new sentence.	
Revision 17	2009-03-16 18:50:19	ranjeeth
Revision 16	2009-03-16 11:36:49	RickMoen
	A couple of punctuation nits	
Revision 15	2009-03-16 11:21:14	RickMoen
	Corrected numerous run-on sentences, punctuation and grammar errors, and questionable idiom.	
Revision 14	2009-03-15 10:27:24	BordenRhodes
	Cleaned up basic grammar and spelling	
Revision 13	2009-03-15 09:52:41	jdd

Revision 12	2009-03-15 09:51:37	jdd
	add link to the manual of avr-libc	
Revision 11	2009-03-14 21:47:18	jdd
	end of basic conversion	
Revision 10	2009-03-14 21:40:18	jdd
Revision 9	2009-03-14 21:39:26	jdd
Revision 8	2009-03-14 21:33:04	jdd
	add the image	
Revision 7	2009-03-14 21:27:59	jdd
Revision 6	2009-03-14 21:26:48	jdd
Revision 5	2009-03-14 21:25:13	jdd
	Firts step - conversion fro html by jdd and basic format edition	
Revision 4	2009-03-14 21:22:37	jdd
Revision 3	2009-03-14 21:18:25	jdd
Revision 2	2009-03-14 21:13:09	jdd
Revision 1	2009-03-14 21:10:33	jdd

Table of Contents

HOWTO	2
AVR Microcontrollers in Linux HOWTO	2
Licence	2
What Is a Microcontroller?	3
Software Required	3
Hello World	4
Author	5
Last version	6

HOWTO

AVR Microcontrollers in Linux HOWTO, Copyright (C) 2009 Ranjeeth p t
(ranjeeth_gecmail[at]yahoo[dot]com)

This HOWTO is for readers wishing to program an AVR microcontroller using a GNU/Linux machine. For burning your code, we will be using a parallel port. You may need other electronics components (like a few resistors, capacitors, parallel port connector, etc.), which can be bought from any electronics shop.

AVR Microcontrollers in Linux HOWTO

Licence

Permission is granted to copy, distribute, and/or modify this document under the terms of the GNU Free Documentation License, Version 1.2, or any later version published by the Free Software Foundation; with no Invariant Sections, no Front-Cover Texts, and no Back-Cover Texts. A copy of the license is included in the section entitled "GNU Free Documentation License".

GNU Free Documentation License [http://wiki.tldp.org/
LdpWikiDefaultLicence#GNUFreeDocumentationLicense]

What Is a Microcontroller?

A microcontroller is a single-chip computer. It has internal RAM, ROM, timers, counters, interrupt circuitry, I/O ports, analog comparators, serial USARTs, analog to digital converters, watchdog timers, and a RISC architecture. When you are using a microprocessor, you cannot program it alone. You need other components, like RAM, ROM, timers, etc. For programming, you should know its architecture thoroughly: You must read the datasheet for your microcontroller.

Software Required

binutils: Tools like the assembler, linker, etc.

gcc-avr: The GNU C compiler (cross-compiler for avr).

avr-libc: Package for the AVR C library, containing many utility functions.

uisp: A Micro In-System Programmer for Atmel's AVR MCUs (for burning code to MCUs' memory).

The following Atmel microcontrollers are supported by avr-gcc in Linux:

at90s Type Devices

at90s2313, at90s2323, at90s2333, at90s2343, at90s4414, at90s4433, at90s4434, at90s8515, at90s8515, at90s8515, at90s8535, at90s1200.

atmega Type Devices

atmega103, atmega603, atmega8, atmega48, atmega88, atmega8515, atmega8535, atmega16, atmega161, atmega162, atmega163, atmega165, atmega168, atmega169, atmega32, atmega323, atmega325, atmega3250, atmega64, atmega645, atmega6450, atmega128.

attiny Type Devices

attiny22, attiny26, attiny26, attiny13, attiny13, attiny13, attiny13, attiny2313, attiny11, attiny12, attiny15, attiny28.

Other AVR Devices

avr2, at90c8534, at86rf401, avr3, at43usb320, at43usb355, at76c711, avr4, avr5, at90can128, at94k, avr1.

binutils: Programs to manipulate binary and object files that may have been created for Atmel's AVR architecture. This package is primarily for AVR developers and cross-compilers.

gcc-avr: The GNU C compiler, a fairly portable optimising compiler that supports multiple languages. This package includes C language support.

avr-libc: Standard library used for developing C programs for Atmel AVR microcontrollers. This package contains static libraries, as well as needed header files.

uisp: Utility to program AVR chips with object code created by gcc-avr. It supports in-system programming.

You download the above packages untar, configure, and install it. If you are using Debian or Ubuntu, these packages are available in your distribution: Install them using apt or synaptic package manager.

Hello World

We are writing **hello world** for the atmega8 microcontroller, which has a 28-pin, 8-bit, RISC architecture.

Before proceeding, have a look at this manual about `__avr-libc__` [<http://www.nongnu.org/avr-libc/user-manual/>], which will help you program better, and understand. Also, refer to the datasheets for the various AVR microcontrollers.

Here is our first program:

```
/* ledblink.c, an LED blinking program */
#include<avr/io.h>
#include<util/delay.h>
void sleep(uint8_t millisec)
{
    while(millisec)

        {
            _delay_ms(1); /* 1 ms delay */
            millisec--;
        }
}
main()
{

    DDRC |=1<<PC2; /* PC2 will now be the output pin */
    while(1)
    {

        PORTC &= ~(1<<PC2); /* PC2 LOW */
        sleep(100); /* 100 ms delay */

        PORTC |= (1<<PC2); /* PC2 HIGH */
        sleep(100); /* 100 ms delay */
    }
}
```

Code Explanation

The GNU C compiler for the Atmel family identifies all functional units within the microcontroller with meaningful names. Thus, writing `PORTC=0xff` will result in the compiler generating machine code that writes 0xff to I/O port C, which will set all port C pins to logic high. Because ports are bidirectional, we must decide whether each pin should act as input or output. If the *i*'th bit of a register called DDRC (data direction register C) is 1, then the *i*'th pin of PORTC's *i*'th pin will be an output. Otherwise, it will act as an input pin. (Note that pin and bit numbers start at zero.) To make an LED blink, you have to make a pin high, then low. (Here, we use PORTC's 2nd port. That is, PC2 will be the 25th pin.) There should be a delay between the two. This is what the rest of the code does. For the delay, we use built-in function `_delay_ms(1)`, which causes a 1 ms delay.

Compilation

```
avr-gcc -mmcu=atmega8 0s ledblink.c o ledblink.o
```

which will result in object file ledblink.o. Now, we will convert it to hex file, suitable for burning to the microcontroller's memory.

```
avr-objcopy -j .text -j .data -O ihex ledblink.o ledblink.hex
```

We are converting it to a hex file because, for burning the code to atmega8, we will use uisp, whose input file must be a .hex file.

Notice that you can *less* the ledblink.hex file.

```
:1000000012C02BC02AC029C028C027C026C025C0C6
:1000100024C023C022C021C020C01FC01EC01DC0DC
:100020001CC01BC01AC011241FBECFE5D4E0DEBF28
:10003000CDBF10E0A0E6B0E0EAE8F0E002C0059035
:100040000D92A036B107D9F710E0A0E6B0E001C0EC
:100050001D92A036B107E1F70CC0D2CF282FE4ECF7
:10006000F9E004C0CF010197F1F721502223D1F725
:100070000895CFE5D4E0DEBFCDDBFA29AAA9884E66A

:0A008000EDDFAA9A84E6EADFF9CF6B
:00000001FF
```

Burning the Code

Hardware

We will be using the parallel port for burning. First, we have to develop a burning circuit for it.

This is the circuit for the atmega8 microcontroller. Pin 9 & pin 10 are connected by a 4 MHz crystal oscillator, which is the external clock. The bottom right connector is for a parallel port.

If you are using any other microcontroller, as mentioned above, you should change accordingly. }}}

You should watch for *RESET,XTAL1,XTAL2,SCK,MISO,MOSI pins*, and connect.

Software

Now, we will burn ledblink.hex to the microcontroller.

```
uisp -dprog=dapa -dlpt=0x378
```

You should get message *Atmega8 Found*.

dprog is the programming method specifier, which in this case is *dapa*, i.e., Direct AVR Parallel Access. *dlpt* is for the parallel device setting, which is 0x378, the parallel port's device address.

```
uisp -dprog=dapa -dlpt=0x378 --erase
```

Will erase the microcontroller's code.

```
uisp -dprog=dapa -dlpt=0x378 --upload if=ledblink.hex
```

Will *upload* the *Input File* ledblink.hex

Notice that you can see the LED at pin 25 blinking.

Author

Comments to: [mailto:ranjeeth_gecmail\[at\]yahoo\[dot\]com](mailto:ranjeeth_gecmail[at]yahoo[dot]com)

Ranjeeth Weblog [<http://ranjeethpt.wordpress.com>]

Govt Engg College Sreekrishnapuram,

Palakkad,Kerala India.

Last version

You may find the last up-to-date version of this HOWTO on the LDP wiki [<http://wiki.tldp.org/Avr-Microcontrollers-in-Linux-Howto>].